



**L1= FRONT RIGHT**  
**L2= FRONT LEFT**  
**A1= DRIVE AXLE LEFT**  
**A2= DRIVE AXLE RIGHT**  
**Z1= THIRD AXLE LEFT**  
**Z2= THIRD AXLE RIGHT**



**This is a basic wiring diagram for a ABS C2 system, some ECU'S in this range may differ slightly.**

**The ECU numbers this diagram applies to are as follows:  
 ( all numbers start with 446 003 ...)**

**038. 034. 039. 040. 044. 051. 054. 062. 064. 066. 068. 069. 070.  
 072. 078. 079.**